



ISOMETRIC VIEW OF LETDOWN CHANNEL AND DIVERSION BERM



INSTALL 18" U-ANCHOR IN 2' INCREMENTS OR STAINLESS STEEL ZIP TIES INSTALLED IN 1' INCREMENTS ALONG MAT ABUTMENTS


ADJACENT FLEXAMAT PLUS PANEL

ABUTMENT METHOD FOR SEAMS WITH EXTENSIONS




6" UNDERLAYMENT EXTENSION
12" GEOGRID EXTENSION


FLEXAMAT PLUS PANEL WITH EXTENSIONS



METHOD FOR TREATING EDGES EXPOSED TO SURFACE SHEET FLOW



ABUTMENT METHOD FOR SEAMS WITHOUT EXTENSIONS




RECYCLEX TRM UNDERLAYMENT PLACED EVENLY UNDER EACH MAT

FLEXAMAT PLUS PANEL WITH EXTENSIONS


RECYCLEX TRM UNDERLAYMENT PLACED EVENLY UNDER EACH MAT

18" U-ANCHOR

ANCHOR TRENCH AND PERPENDICULAR OVERLAP SEAMS



FLEXAMAT PLUS UNDERLAYMENT



FLEXAMAT PLUS - LETDOWN ARMORING

CONSTRUCTION NOTES:

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. GRADE CHANNEL SO THAT WATER WILL FLOW DOWN THE CENTER OF THE CHANNEL AND BE CONTAINED TO THE CHANNEL. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE SHALL PROVIDE A FIRM UNYIELDING FOUNDATION FOR THE MATS.
3. APPLY SEED DIRECTLY TO THE PREPARED SOIL PRIOR TO FLEXAMAT INSTALLATION. USE SEED PER PROJECT SPECIFICATIONS.
4. INSTALL FLEXAMAT ROLLS. AVAILABLE WIDTHS ARE 4', 5.5', 8', 10', 12', 16', & 15.5' (WITH 6" PLUS UNDERLAYMENT EXTENSION AND 12" GEOGRID EXTENSION) AVAILABLE IN CUSTOMER LENGTHS. FOR WIDER WIDTHS, INSTALL MATS ADJACENT TO EACH OTHER. (CONTACT MANUFACTURER FOR DETAIL ADDRESSING LONGITUDINAL SEAMS.)
5. AT THE TOP OF THE CHANNEL, THE INITIAL LEADING EDGE OF FLEXAMAT EXPOSED TO CONCENTRATED FLOWS SHALL BE EMBEDDED 18" VERTICALLY INTO THE SUBGRADE TO SERVE AS AN ANCHOR TRENCH. THE TRENCH SHALL BE FILLED AND COMPACTED WITH SUITABLE FILL OR OTHER (AS SPECIFIED BY EOR).
6. FOR ADDITIONAL SECTIONS OF MAT, OVERLAP THE DOWNSTREAM SECTION 18" WITH UPSTREAM SECTION OF MAT. PRIOR TO INSTALLING OVERLAP, FLIP UPSTREAM MAT BACK 24". EXCAVATE 2.25" OF TOPSOIL 18" FROM THE END OF THE UPSTREAM MAT. DOWNSTREAM SECTION IS LAID IN THE SHALLOW TRENCH. LIGHTLY SPREAD TOPSOIL OVER INITIAL EDGE OF DOWNSTREAM MAT.
7. INSTALL 18" U-ANCHORS IN 2' INCREMENTS ACROSS THE OVERLAP. INSTALL ANCHORS DIRECTLY BEHIND BLOCKS. U-ANCHORS CONSIST OF #3 REBAR U-ANCHOR WITH 18" LEGS.
8. AT THE END OF THE ARMORED CHANNEL, EMBED THE MAT 18" IN A TERMINATION TRENCH. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOILS.
9. FOR APPLICATIONS WHERE DIVERSION BERMS DIRECT WATER FLOW INTO THE MAIN FLEXAMAT LETDOWN CHANNEL, THE DIVERSION BERMS MUST BE ARMORED WITH FLEXAMAT TO THE TOP OF THE BERM.

MOTZ ENTERPRISES, INC.

Flexamat

(513)772-6689

Info@Flexamat.com

Flexamat.com

